



CAMERA SETUP

PRO SERIES CAMERAS



Three loop wires set the camera output. **Cut a loop to switch that option; rejoin it to switch back.** Test the picture before you seal the cable.



White — Mirror / Non-Mirror

Joined = mirror (rear), cut = non-mirror (front). Switches between rear-view and front-view orientation.



Blue — Vertical Flip

Joined = normal, cut = flipped. Corrects the image when the camera is mounted upside down.



Green — Parking Guidelines

Joined = on, cut = off. Turns the on-screen guidelines on or off.

Scan the QR on your info card

SMS +61 411 101 737